

www.proto-advantage.com  
PCB3006-1  
Footprint Check 1:1 scale plot

(Ensure your PDF viewer page scaling  
is set to "none" before printing)

